



PHOTOCENTRIC RESIN CLEANER INSTRUCTIONS

USE INSTRUCTIONS

1. Place printed model in ultrasonic unit without heat for 2-4 minutes but no longer than 5 minutes.
2. Rinse model with clean water.
3. Place model in a container with water (40C-60C) under UV light for 2h (1h on each side). If using a Post Curing Unit, post processing should be 1h in water (40C-60C) under UV then 1h in Cure box at 80C or 2h at 60C

Note: Change cleaner when it no longer removes the stickiness from objects.

IF ON SKIN, Wash with plenty of water/soap and water.

IF INHALED, remove person to fresh air and keep at rest in a position comfortable for breathing.

IF IN EYES, rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do so. Continue rinsing.

Material harmful if swallowed

Call a POISON CENTER or doctor if you feel unwell.

Disposal: Empty to a suitable container and dispose of according to local legislation

