


COMBINATION LOCK INSTRUCTIONS

UNLOCK MODE:

TO UNLOCK, ALIGN PRESET OR CURRENT COMBINATION (A) AND PULL PLUNGER OUTWARD (B) UNTIL INDENTATION IN PLUNGER IS VISIBLE NEXT TO ARROW (C). **FACTORY PRESET: "1 1 1 1"**



CHANGING LOCK COMBINATION:

1. SET LOCK TO UNLOCK MODE (SEE ABOVE)
2. ON REVERSE SIDE, MOVE THE SLOT TO THE LEFT OF THE COMBINATION NUMBERS (D) DOWNWARD UNTIL IT STOPS (E).
3. SET NEW COMBINATION ON THE FRONT SIDE OF LOCK IN LINE WITH ARROW.



WARNING: BACKUP CODE NOT AVAILABLE IF COMBINATION IS FORGOTTEN OR LOST.

4. MOVE SLOT UPWARD TO ORIGINAL POSITION UNTIL IT STOPS (F).

