

Activator for RK-1300 & RK 1500



Activator for RK-1300/1500

Technical data

Viscosity Activator	very thin liquid mPa.s
Specific weight Activator	0,87 g/cm ³
Colour activator	colourless, transparent
Consumption activator (depending on surface structure)	30 - 150 g/m ²
Evaporation time activator at +20°C	5 min.
Effectiveness activator after application at +20°C	max. 30 days

Pretreatment of the surface

To ensure perfect bonding, the surfaces to be joined must be clean and dry (to clean and degrease use WEICON Surface Cleaner). The highest strength values can be achieved through additional pre-treatment of the surfaces, such as roughening using blasting or abrasive agents.

Several plastics, in particular polyamide, PTFE, polyolefin etc. are only to be bonded after special surface treatment, for example using fluoridation, low-pressure plasma, corona, flame impingement etc.

Processing

Processing of the RK Activator

The RK Activator is applied, depending on the size of the bonding gap, on either one side or both sides of the surfaces to be bonded (brush, spray, dip). In case of bond lines with a max. of 0.4 mm in width, the Activator only needs to be applied on one side, for bond lines of up to a max. of 0.8 mm in width and/or rough, porous or passive surfaces (chrome, nickel etc) the Activator must be applied on both sides.

For smooth plastic and metal surfaces, approx. 30 g/m² is necessary, for rough and porous surfaces up to 150 g/m² of Activator may be necessary. The evaporation time at room temperature (+20°C) is at least 5 minutes.

A significant advantage to other adhesive systems is that the coated components can be stored up to 30 days at room temperature (+20°C) without losing effectiveness.

Processing of the RK Adhesive

The Adhesive is applied only on one side and normally on the surface which is not coated with Activator. The width of the bond line can be up to 0.80 mm (only if the Activator is applied on both sides). Bond lines of 0.15 mm to 0.25 mm in width always have the highest tensile shear strength.

Processing temperature

The processing should take place at room temperature (approx.

Storage

WEICON RK-Activator has a shelf life of at least 6 months if stored in a dry room at a constant temperature of approx. +20°C. At temperatures between +1°C and +7°C the shelf life can be extended up to 24 months. This applies for closed original units which have not been directly or indirectly exposed to sunrays. In case of storage temperatures exceeding +40°C and high humidity, the shelf-life is considerably shortened.

Note

Any product specifications and recommendations given herein must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do warrant the continuously high quality of our products being free from defects in accordance with and subject to our General Sales Conditions. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

Health and Safety

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

WEICON GmbH & Co. KG (Headquarter)

Königsberger Str. 255 · DE-48157 Münster
P.O. Box 84 60 · DE-48045 Münster
Germany

Tel. +49 (0) 251 / 93 22-0
Fax +49 (0) 251 / 93 22-244
Fax +49 (0) 251 / 93 22-233 Export
www.weicon.de · info@weicon.de

WEICON Middle East L.L.C.

Jebel Ali Ind Area 3 · P.O. Box 118 216
Dubai · U.A.E

Phone +971 4 880 25 05
Fax +971 4 880 25 09
Mobile +971 50 545 99 83
www.weicon.ae · info@weicon.ae

WEICON Inc.

20 Steckle Place · Unit 20
Kitchener · Ontario · N2E 2C3
Canada

Phone +1 519 896 5252
Fax +1 519 896 5254
Cell +1 519 590 5168
www.weicon.ca · info@weicon.ca

WEICON Kimya Sanayi Tic. Ltd. Şti.

Yenibosna Mahallesi Yalçın Koreş Caddesi
Arifağa Sokak No: 29 Kat: 3
34530 Yenibosna – İstanbul Turkey
www.weicon.biz.tr · info@weicon.biz.tr

WEICON Romania SRL

Str. Podului Nr.1
547176 Budiu Mic (Targu Mures)
www.weicon.com · office@weicon.com