

Surface Cleaner

Technical Datasheet

Create Date: 06.06.2016 - Page 1/1



Health and Safety

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.



Pretreatment of bonding surfaces

WEICON Surface Cleaner is used for the cleaning and degreasing of surfaces to be joined or sealed with WEICON adhesives and sealants.

Surface Cleaner can be applied on materials like metal, glass, ceramics and most plastics.

WEICON Surface Cleaner can be used, for example, to clean and degrease machine components in the course of maintenance work.

Technical data

Colour	clear
Odour	citrus
Temperature resistance	°C
Shelf life min.	24 months
Special features	evaporates without leaving residues
Suitable for use with	WSD 400 + WPS 1500

Processing

Dip in part to be cleaned, or brush or spray on Surface Cleaner sufficiently (e.g. with an Air Pressure Can). Use a clean cloth or nonwoven fabric to wipe off wet residues making sure that impurity and solvent remainders are removed. Repeat the cleaning process if necessary. Let the solvents evaporate until the surfaces have dried.

Storage

Keep in closed original container. Protect from direct solar radiation. Storage temperature may not exceed +50 °C.

Store container at cool and aired place. Store in a dry place.

Note

Any product specifications and recommendations given herein must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do warrant the continuously high quality of our products being free from defects in accordance with and subject to our General Sales Conditions. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified

WEICON GmbH & Co. KG (Headquarter)

Königsberger Str. 255 · DE-48157 Münster P.O. Box 84 60 · DE-48045 Münster Germany

Tel. +49 (0) 251 / 93 22-0 Fax +49 (0) 251 / 93 22-244 Fax +49 (0) 251 / 93 22-233 Export www.weicon.de · info@weicon.de

WEICON Middle East L.L.C.

Jebel Ali Ind Area 3 · P.O. Box 118 216 Dubai · U.A.E

Phone +971 4 880 25 05 Fax +971 4 880 25 09 Mobile +971 50 545 99 83 www.weicon.ae · info@weicon.ae

WEICON Inc.

20 Steckle Place · Unit 20 Kitchener · Ontario · N2E 2C3

Phone +1 519 896 5252 Fax +1 519 896 5254 Cell +1 519 590 5168 www.weicon.ca · info@weicon.ca

WEICON Kimya Sanayi Tic. Ltd. Şti.

Yenibosna Mahallesi Yalçın Koreş Caddesi Arifağa Sokak No: 29 Kat: 3 34530 Yenibosna – Istanbul Turkey www.weicon.biz.tr · info@weicon.biz.tr

WEICON Romania SRL

Str. Podului Nr.1 547176 Budiu Mic (Targu Mures) www.weicon.com · office@weicon.com