

SINAMICS™

# **G120P Supplemental System Components**

Webserver Module SAM

IOP-2-BT

BOP-2

Blanking Cover









- Webserver Module SAM (Smart Access Module) for access to drives over WiFi using a PC, smartphone, or tablet
- Operator panel IOP-2-BT (Intelligent Operator Panel) with application-specific commissioning wizards, clear text display, and USB interface
- Operator panel BOP-2 (Basic Operator Panel), menu driven and 2-line display
- Blanking cover, degree of protection IP55/UL Type 12
- Drive operating temperature 0...50 °C, with blanking cover 0...60 °C

### Anwendung

Operator panels for comfortable on-site commissioning, control as well as diagnostics, and simple cloning of complete VSD data sets. As an option, a blanking cover (IP55) can be used in lieu of the operator panel to cover the interface.

- Webserver module SAM (Smart Access Module)
  For fast commissioning, parameterization, and maintenance of G120P drives with WiFicapable PC, smartphone, or tablet.
- Intelligent Operator Panel IOP-2-BT, degree of protection IP55/UL Type 12 Menu-driven with clear text display, help function and application wizards for commissioning, diagnostics, and operation of standard drives.
- Basic Operator Panel BOP-2, degree of protection IP55/UL Type 12
   Menu-driven tool with 2-line display for fast and comfortable commissioning of the VSD.
   Simultaneous display of parameter and parameter value. Commission a drive without a print out of the parameter list.

## Webserver Module SAM

#### Overview



- 1 COM-LED: Shows communication status
- 2 WLAN-LED: Shows WiFi connection status
- 3 Reset button
- 4 WiFi On/Off button

#### On the rear:

- Type plate
- 1 RS232 plug

#### **Functions**

- Wireless operation by using a mobile device or PC.
- Provides users with an integrated webserver for all webpages and data items.
- Integrated description of parameters, diagnostics, and settings in different languages.
- Open for future function extensions, assistants, and languages.
- Degree of protection IP55 provides protection against internal dust deposits and against splash water (from all directions).
- Supports WAP-2 and HTTPS.
- HTML5 user interface provides Interactive view with color information that allow user feel of operating just like apps.

#### Overview



- 1 ESC: Return to menu status or previous display
- 2 Sensor control panel OK button: Selec menu items
- 3 INFO: Explanatory help texts
- 4 EIN: Switch on and start the inverter
- 5 HAND/AUTO: Switch from automatic to manual operation
- 6 AUS: Switch off the inverter

#### On the rear:

- Type plate
- 1 USB port
- 1 RS232 plug
- 4 door-mounting screw recesses

# **Functions**

- Very user-friendly and powerful operator panel for SINAMICS G120P standard drives.
- Easy commissioning, for beginners as well as drive experts thanks to clear text displays, menus, and interactive application wizards.
- Fast commissioning wizard for general commissioning.
- Drive commissioning without printed parameter lists by displaying the parameters in clear text, explanatory help texts, and parameter filters.
- Support of repeat commissioning by loading a parameter list to other drives of the same type (up to 16 parameter sets can be saved).
- Includes wizards for simple configuration of important applications including pumps, fans, and compressors.
- Diagnostics of errors and warning messages displayed in clear text.
- Graphical or numeric visualization of up to two process values.
- Updates and extensions via the integrated USB interface:
  - Drag & Drop to add new drive types, user languages and wizards.
  - Powered via USB interface during updates.
- Pre-installed language packages in German, English, French, Italian, and Spanish.
- Language packages, updates, and extensions are available at no charge under: http://support.automation.siemens.com/WW/view/en/30563514/130000

#### New in IOP-2-BT

- Fully compatible with the new CU230P-2 firmware V4.7
- More internal memory for extra flexibility (language and firmware updates).
- Reduced loading times of wizards and when searching parameters.
- Enhanced commissioning wizard:
  - Direct selection of motor temperature sensors during commissioning.
  - Better efficiency by entering the motor cos phi.
  - Tunable motor current for even better control and motor protection.
  - Full compatibility with the new HVAC macros for quick application commissioning.

# BOP-2

## Overview



- 1 ESC: Return to menu status or previous display
- 2 Arrow buttons: Navigate menus and set values
- 3 OK: Select and confirm values
- 4 ON: Switch on and start the inverter
- 5 HAND/AUTO: Switch from automatic to manual operation
- 6 OFF: Switch off the inverter

#### On the rear:

- Type plate
- 1 RS232 plug
- Door-mounting screw recesses

## **Funktionen**

- Simple commissioning of standard drives with menu-driven 2-line display.
- Drive commissioning without printed parameter lists by displaying the parameters in clear text, explanatory help texts, and parameter filters.
- Direct, menu-driven and easy diagnostics.
- Numeric visualization of up to two process values for simple monitoring.
- Support of repeat commissioning by loading a parameter list to other devices of the same type.

# Ordering

Type (ASN)	Order no. / MLFB	Description
G120P-SAM	6SL3255-6AA00-5AA0	SINAMICS G120 Smart Access, Webserver Module (SAM)
G120P-IOP-2-BT	6SL3255-6AA00-4JA2	SINAMICS G120P IP20/IP55, Intelligent Operator Panel (IOP-2-BT)
G120P-BOP-2	6SL3255-6AA00-4CA0	SINAMICS G120P IP20/IP55, Basic Operator Panel (BOP-2)
G120P-BCOVER	6SL3256-6BA00-0AA0	SINAMICS G120P IP20/IP55, Blind Cover (BCOVER)

# Accessories

Typ (ASN)	Bestellnummer / MLFB	Beschreibung
G120P-Door-Kit	6SL3256-6AP00-0JA0	SINAMICS G120P Door kit (IP54) / BOP-2 (IP55), KIT UL TYP12 for Intelligent Operator Panel IOP-2 and Basic Operator Panel BOP-2 consisting of: Seals, mounting materials, and connection cable (5 m)

# Product documentation

Document	Content	Document ID	
Operating Instructions G120 Smart Access	Detailed information on operating the SINAMICS G120 Smart Access	A5E43332549	
Operating Instructions IOP-2-BT	Detailed information on operating the SINAMICS IOP-2-BT	A5E39549448B AD	
Operating Instructions BOP-2	Detailed information on operating the SINAMICS BOP-2	A5E37143404A AA	

# System requirements for G120 Smart Access

Device with wireless network adapter	Operating system	Recommended webbrowser
PC	Windows 7	<ul><li>Google Chrome 64.0.3239 or higher</li><li>Internet Explorer 11.0.9600 or higher</li></ul>
	Windows 10	Microsoft Edge 38.14393.1066 or higher
Smartphone / Tablet	iOS 10.2 or higher	<ul><li>Firefox 10.6 or higher</li><li>Safari</li></ul>
	Android 6.0.1 or higher	<ul><li>Google Chrome 62.0.3202.84 or higher</li><li>Firefox 58.0.2 or higher</li></ul>

# **Dimensions**

Device	Width	Height	Depth
SINAMICS G120 Smart Access, Webserver-Modul		108.5 mm	17.3 mm
SINAMICS G120P IP20 / IP55, Intelligent Operating Panel (IOP-2-BT)	70	106.9 mm	19.7 mm
SINAMICS G120P IP20 / IP55, Basic Operating Panel (BOP-2)	70 mm		
SINAMICS G120P Blanking Cover (BCOVER)			